



OWNER'S MANUAL ADDENDUM for the description of the wall mounting option on page 5 in the L series o/m, for the models L810, L820, LC2.

The page mentions in two places where you lower the loudspeaker “onto its keyholes at the rear of the speaker”.

On these models, at the rear, there are four pairs of threaded inserts, and the holes are blocked with plastic plugs. *The included wall brackets contain the keyholes.*

1. Remove the plastic plugs from the pair of holes you will need at the rear of the loudspeaker.
2. Attach the wall brackets to the loudspeakers with the supplied screws.
3. Then you can hang the loudspeaker from its keyholes onto your prepared wall screws.

If for some reason you cannot locate the wall brackets, you can order them from the JBL parts dept. The part number is 353355-001.